

## 12-Foot Spray Bar Assembly

To whom it may concern,

Advanced Chemical Technologies supplies both silane and the equipment for the application of silane. Such equipment is often shipped in multiple pieces, so we are providing this resource to help users with assembly of our 12-foot spray bar. The spray bar is made up of:

- Trapezoidal wheelbase
- Two attachable wheels
- Central spray bar
- Left spray bar
- Right spray bar
- Handlebar with valve connections
- Bar with hose attached

All bolts, cotter pins, and hose clamps are attached to the equipment. The recommended equipment for assembly:

- 14 mm wrench
- 28 mm wrench
- Adjustable wrenches
- Adjustable pliers
- Flathead screwdriver

When removing the packaging, be careful to not damage the hoses or spray tips.

When assembling the spray bar, make sure that all hoses are attached, and the bolts and clamps are tightened.

When using the spray bar, walk at a steady pace so that silane is applied evenly at a uniform rate.

After the silane has been applied, clean the spray bar by running mineral spirits through it.





































